



- 1. profile fascia lat.
- 2. glass 12mm - 21,52mm
- 3. inlay (ABS)
- 4. safety wedge (ABS)
- 5. rubber (EPDM)
- 6. anchor
(or comparable anchor)
- 7. blind plug (ABS)
- 8. cap rail (corrimano) Ø42,4mm
(more cap rail options)
- 9. cartongesso con la funzione di
nascondere la fascia di sostegno

Article: PARAPETTO IN VETRO MOD: 336		Date: 28.02.2014
Project: FASCIA LATERALE A SCOMPARSA		CANTIERE: _____
Scale:	COMMITTENTE _____	

